



# HP WallArt Suite



# JDF Workflow Integration

December 2015

HP WallArt Team




# Enabling JDF in HP WallArt Basic Concept

# JDF/RIP's Automation

## More efficiency on your workflow

How can it accelerate the process?

- 1 Sends ready-to-print files directly from your web2print
- 2 RIP automatically downloads your files, without manual interaction



## AUTOMATIC PROCESS



HP WallArt Web2Print



File Ripping



Printing




# Enabling JDF in HP WallArt Suite


## How it works

# Enter Workflow Integration settings

1 Click on  Settings




2 Click on [System Configuration](#)



# Configure JDF Connection settings

3 Scroll down to Workflow Integration. There you will find the JDF Integration options.




Note this personalized URL. You will need it in further steps to configure your RIP.



# Configure JDF Connection settings

- 4 Click to check the “Enable JDF connectivity”, and ensure that “Enable JDF authentication” is also checked.

Configure any additional options, if needed.



**Workflow Integration**

**JDF Connection**

<https://jdf.hpwallart.com/bcndemo>

Enable JDF connectivity ⓘ

Enable JDF authentication ⓘ


Use single page PDF in JDF job ticket ⓘ

**Connect to another Print Service Provider**

Enable redirection ⓘ

# Configure JDF Connection settings

- 5 Remember to save any changes clicking the [Save](#) button.



The screenshot shows a configuration page for JDF Connection settings. It is divided into three sections: Workflow Integration, Connect to another Print Service Provider, and Certifications. In the Workflow Integration section, the JDF Connection URL is set to https://jdf.hpwallart.com/bcddemo. The 'Enable JDF connectivity' and 'Enable JDF authentication' checkboxes are checked, while 'Use single page PDF in JDF job ticket' is unchecked. In the Connect to another Print Service Provider section, the 'Enable redirection' checkbox is unchecked. In the Certifications section, 'Can provide installation service' is unchecked, while 'Certification 3M MCS' and 'Certification Avery ICS' are checked. At the bottom right, there are 'Cancel' and 'Save' buttons.

**Workflow Integration**

JDF Connection  
https://jdf.hpwallart.com/bcddemo

Enable JDF connectivity ⓘ  
 Enable JDF authentication ⓘ  
 Use single page PDF in JDF job ticket ⓘ

**Connect to another Print Service Provider**

Enable redirection ⓘ

**Certifications**

Can provide installation service  
 Certification 3M MCS  
 Certification Avery ICS

Cancel Save

In the next steps, you will setup your RIP.





# HP WallArt Set up in


Only for PrintFactory 5



# Set up HP WallArt in GMG RIP

Only for PrintFactory 5 and ProductionSuite 2.2


- 1 Start RIP and go to **Edit\Preferences**



# Set up HP WallArt in GMG RIP

## Only for PrintFactory 5 and ProductionSuite 2.2


- Go to the Accounts tab and add the personalized URL shown in the step 3 of your HP WallArt Suite setup.



# Set up HP WallArt in GMG RIP

## Only for PrintFactory 5 and ProductionSuite 2.2


- 3 Back in the RIP application define a printer and a queue. Select a queue. If you do not select a queue and try to access the HP WallArt you will receive a warning. With a queue selected go to **View\HP WallArt**



# Set up HP WallArt in GMG RIP

Only for PrintFactory 5 and ProductionSuite 2.2

- 4 You now have access to the HP WallArt job list as displayed in the following picture.



# Thank you

